If your kit does not have a black wire, simply disregard it in this guide.

Attach the wires as shown in the image below and attach the kit's DB9 connector to the JB4.



